

FIGARO INSTALLATION WARNINGS

- Handle the speakers by taking the edges of MDF panel! NEVER grab it by put your hands on the components! Each component has little breakable copper wires.
 - Connections for the Figaro Passive speaker require 2 x 2mm red and black speaker cable. Figaro Active speaker requires fully shielded signal/microphonic cable.
 - To install Figaro speakers you need at least 10cm of space inside your false ceiling.
 - All the plasterboard panels composing the false ceiling must not be physically separated or divided by silicon glue in order to not interrupt the vibration spread through the entire surface, otherwise it will sound only panels with continuity.
 - Use at least 6 M6 screws on MDF board of the Figaro Speaker to well fix the product to the plasterboard panel. Screw from the bottom to the top of the panel.
 - Don't place Figaro close to the ceiling frame bars or lights bars to avoid distortions. Install the speaker in the center of one plasterboard panel.
 - In presence of pending elements or lights they implied holes into the plasterboard, use silicone glue to fix them and avoid "tickling" effect with vibrations.
- (- during the false ceiling creation phase, remember to apply the net on the joints before filling the plasterboard plates to prevent eventual cracks)
- The speaker line connections require competence in audio. Ask to an expert!
 - Always check that cables has been well fixed to the speakers and verify all the wires have no stripped points , especially around plugs or jack, to prevent interferences or noisy effect.

esarc
H I - T E C H



sito WWW.ESARC.COM – mail INFOESARC@ESARC.COM